

Aqua-Flor ® (WB) Concrete Finish

Preparation

Ensure that the surface is clean and free from dust and grease.

Clean with Swift low foam diluted accordingly to remove any grease or contaminants.

Allow the surface to fully dry before applying the Aqua-Flor.

Application

To ensure Aqua-Flor is applied evenly, use either a Synthetic Applicator and pad, a Microfibre Roller or a 'Padco' T-Bar Coater with a blue foam sleeve.

The size of the floor area, together with the time allowed for coating will determine the type of applicator to be used.

After the first coat of Aqua-Flor is dry, apply second and subsequent coats in the same manner.

Drying time: Approximately 1 hour (at 20°C/50% R.H.*) Please note that poor ventilation, low temperature and/or high humidity will all extend or affect product drying and curing.

Curing time: Full cure 48-60 hours (at 20°C/50% R.H.*).

Will take light traffic after 12 hours depending on temperature.

Avoid covering the surface with plastic sheeting, rugs, etc., as this will affect the curing process.

Maintenance

Floor should be left for a minimum of 5 days before any maintenance programme is implemented.

Clean with a Neutral Detergent diluted in water.

Further Information

Storage: Avoid storing in extreme hot or cold temperatures. Ideally, store between 10°C and 30°C. Protect from frost.

Shelf life: Unopened container - 12 months from date of despatch.

Health and Safety: For product health and safety information, please refer to our Material Safety Data Sheet.