



TIPT TIPTOP Suede Renovators Page 1 of 1

• Imparts a smooth silky feel to the touch

• Stays on the surface for a very long time

• Allows the nap of the suede to continue to move

USES Freshens the appearance of nubuck suede without altering the nap.

TOPCOAT DR2-3-11482-005 TIPTOP NuBuck Renovator 11482 Vibrant

DR2-3-11483-005 TIPTOP NuBuck Renovator 11483 Natural

CLEANER FOR EQUIPMENT ZI330 WATER

APPLICATION EQUIPMENT Conventional airless / airmix or HVLP spray equipment.

APPLICATION Spray apply. Can be applied on to any colour. When first applied the material will look dark,

once dry it leaves the original colour of the nubuck/suede with a silky feeling surface. The

nap will still move, surface will not harden. Provides a high degree of water resistance.

FURTHER INFORMATION TIPTOP Vibrant will give a slightly deeper colour when fully dried. Please protect from frost.



Coverage







5-600 Pairs/lt 8-10 mins

Touch Dry

Recoat

Time

20 mins

Max

Resistance

Overnight N/A N/A 12 months 5lt

