

SACR SUPER A Creams (hand applied) Page 1 of 1

FEATURES

- High dye formulation which will fill the grain
- Produces a silky smooth, streak-free natural shine
- Designed for all types of leathers
- Excellent results when polished

USES

Hand applied 'streak free' finish for leather.

TOPCOAT

DR4-5-00753-005	SUPER A Cream 753 Neutral
DR4-5-11404-005	SUPER A Cream 11404 Black
DR4-6-AA000-005	SUPER A Cream Promatch
DR4-6-AS000-005	SUPER A Cream Promatch SPECIAL

CLEANER FOR EQUIPMENT

APPLICATION EQUIPMENT

By sponge or lint-free cloth

APPLICATION

Sponge apply, working it well into the leather. Polish with a cloth or rotary mop. Add Carna Pad Wax to the mop will produce a deeper shine. To fill / seal the leather a coat of INTERSPRAY, SILKENE DRESSING or SPRAY CREAM may be applied prior to the cream. On some dull surface leathers, burnish on a rotary mop first, using 20246 Silkene cutting & polishing wax, this will lay the grain down and leave a rich, smooth, even finish.... For 'Semi Aniline' Leather apply the Super A Cream as above, once fully dry apply a coating of the SILKENE DRESSING to finish and seal in.

FURTHER INFORMATION

To lift the gloss level of the finished item, apply a light coat of SPRAY CREAM on top of the 'SUPER A' Cream prior to final polishing.



Coverage	Touch Dry	Recoat Time	Max Resistance	Pot Life	Mix Ratio	Shelf Life	Pack Size
4-500 Pairs/Lt	10-15 mins	20 mins	Overnight	N/A	N/A	12 months	1 & 5lt

330/18

