

## MANUFACTURING INNOVATIVE SOLUTIONS FOR OVER 125 YEARS

the perfect finish
SINCE 1898

### ISF TECHNICAL DATA SHEET

# Steri-Guard SG2 AC - PROMATCH



#### **FEATURES**

- Non biocide "safe to use" hygienic coating
- Fast drying for speedy production schedules
- Quick drying with good flow & marr resistance properties
- High quality pre-cat resin-based formulation

USES	Interior joinery & furniture.					
TOPCOAT	Steri-Guard SG2 AC Promatch					
	Steri-Guard SG2 AC Promatch METALLIC Steri-Guard SG2 AC Promatch SPECIAL					
	Steri-Guard SG2 AC Promatch WHITE					
	Steri-Guard SG2 AC Promatch BLACK					
TOPCOAT CATALYST	AC2-Lo (low odour) Catalyst					
BASECOAT	AC2-Lo (low odour) Primer Filler WHITE					
	AC2-Lo (low odour) Primer Filler GREY					
	AC2-Lo (low odour) Primer Filler CHARCOAL					
	AC2-Lo (low odour) Primer Filler BLACK					
BASECOAT CATALYST	AC2-Lo (low odour) Catalyst					
THINNER FOR SYSTEM	ACT Acid-Cat Thinners					
	No 31 Anti Bloom Retarding Thinners					
CLEANER FOR EQUIPMENT	ISF Spray Gun & Brush Cleaner					
APPLICATION EQUIPMENT	Conventional airless / airmix or HVLP spray equipment.					
MIX RATIO	Steri-Guard SG2 AC Promatch - 9:1					
-	AC2-Lo (low odour) Primer Filler - 9:1					
MIXICATIO	AC2-Lo (low odour) Primer Filler - 9:1					



#### **APPLICATION PROCESS**

Stir & mix the products well prior to use. Once mixed with Catalyst the viscosity may be adjusted with Thinners by up to 10% volume.

Apply a light coat of AC2-Lo (low odour) Primer Filler, allow to dry, de-nib & apply another Primer coat as necessary.

Then after a further de-nib apply a full even coat of the Steri-Guard SG2 AC Promatch.

Allow to dry overnight prior to packing.

#### **FURTHER INFORMATION**

The ISF range of AC2-Lo Systems are now classed 'Lo Formaldehyde' and as such they are a major Health & Safety development. Formaldehyde is deemed to be carcinogenic and a risk to the end user. Our unique manufacture process removes the formaldehyde from both the Part A & B components to make these lacquers MUCH SAFER to use. The actual levels are under 0.1% which is a major breakthrough in Acid Catalysed technologies. Using ISF AC2-Lo Systems the working environment within any Spray Shop will be dramatically improved.

A further improvement in the formulation of these lacquers has also been made. All the butanol (a very pungent solvent) has been removed - this vastly improves the "smell" whilst drying, making them into low odour lacquers.

\*Please ensure that the total system film thickness (DFT) does not exceed 150 microns.

#### **CLEANING & MAINTENANCE**

Clean regularly with a soft dry cloth. When needed wipe with a moist cloth. Neutral cleaning detergents or household cleaners with low amounts of alcohol or waxes can also be used.

To meet the guidance of the drying times stated below the operation Temperatures of both the environment and product will need to be within 18°C - 20°C.

Lower or higher Temperatures of either the environment or product will have an impact on the stated drying times. Please speak with the Technical Team on how to manage any adverse changes.

Storage Temperatures should be maintained above 5°C.

Coverage	Touch Dry	Recoat Time	Max Resistance	Pot Life	Mix Ratio	Shelf Life	Pack Size
7-9 Sq.m/lt	20 mins	60 mins	7 Days	N/A	N/A	12 months	1, 5 & 25lt



#### **ENVIRONMENTALLY FRIENDLY**







Steri-Guard SG2 AC - PROMATCH | Page 2 of 2

This version: March 2025



Thurmaston Boulevard • Leicester • LE4 9HS • United Kingdom Email: sales@isf.co.uk • Telephone: 0116 274 2222